

Trolley Assembly Instructions



Step One

Push in wheels until they click
Brake wheels front only
If multi trolley wheels on outer corners only



Step Two

Push in pedal until it clicks



Step Three

Push in both vertical poles and turn until it locks



Step Four

Hinge Mounting
line up groove with correct side push down firmly



Step Five

Ring Mounting
Make sure hinge and hole in base go on same side
The plastic pins have to block in holes of pole



Trolley Assembly Instructions



Step Six
Insert soft closure mounting



Step Seven
Pedal tube mounting
Insert spring in the tube
Insert tube in the housing



Step Eight
Turn trolley over
Double click pedal clamp to tube
and pedal



Step Nine
Lid mounting attach pins in hole
either side until click

Step Ten
If multi trolley attach bars underneath with screws.

For more detailed Video go to www.filterfab.com Click on help tab for videos

